



SUNPIPE® Composite EPDM Roof Kit



Designed for Tradesman

The new patented SUNPIPE EPDM flashing plate is the result of collaboration between Permaroof UK® and Monodraught® to create the ideal solution for bringing in daylight from EPDM roofs.

Bonding a weathering skirt into the flashing plate made from Firestone® Rubbercover®, the new EPDM SUNPIPE removes the need for fabricating complicated flashing arrangements on site and replaces this lengthy process with just four straight lengths of Permaroof's seam tape, easily installed and weathered into the roof construction in as little as 10 minutes!

SUNPIPE Composite EPDM Roof Kit:

- Designed in accordance with Firestone®
- Whole SUNPIPE system can be fitted in 90 minutes
- It is fully water-tight
- Provides 100% integrity with roof
- Requires no structural alterations
- No maintenance
- Has a 10 years' guarantee & 25 years' life expectancy
- Contains all components needed

Available Sizes

300 mm System	450 mm System	530 mm System
<p>Kitchens, bathrooms, studies, living rooms and landings.</p> <p>Lights up an area of approx. 12 m²</p>	<p>Games rooms, galleried halls, any large areas.</p> <p>Reaches largest possible diameter of SUNPIPE.</p> <p>Still fits within spacing of most roof joints.</p>	<p>Offices, school classrooms, and similar commercial properties.</p>

The Problem

Weathering any kerb or upstand into a flat membrane roof can be a time consuming process. Traditionally, the roofer will have to fabricate their own seal arrangement on site, using multiple types of flashing and tape to ensure the water seal of the roof remains.

The Solution

Designed for tradesman, the SUNPIPE EPDM Flashing Plate can be installed in as little as 10 minutes, cutting the entire process down to as little as 90 minutes. The four lengths of seam tape provided in the kit are all that is required to fit and weather the flashing plate to a Firestone Rubbercover roof.

SUNPIPE Firestone Kit contains all you need:

- Complete SUNPIPE kit with incorporated EPDM Skirt
- 4 m Firestone 3" Seam tape
- 8 No V-Plate washers
- 8 No all-purpose Fasteners
- 0.5 Litres of Firestone Quickprime Plus



Steps

1. Mark position of SUNPIPE, lift integrated EPDM skirt to fasten to roof construction.



3 mins

2. Prime and apply Firestone Seam tape to roof.



7 mins

3. Roll down and seal the skirt against the roof membrane and roll in seal.



10 mins

Ordering Details

Permaroof

0800 1613722

www.permarroof.co.uk

sales@permароof.co.uk

Monodraught Ltd

01494 897700

www.monodraught.com

info@monodraught.com



Watch the full installation process at:
www.youtube.com/monodraughtuk